

Astor ♦ Bannerman

Manually Height Adjustable Table



Owners Manual and Instructions for Use



IMPORTANT
READ THIS
MANUAL
BEFORE USE

Guarantee

This product is guaranteed against all defects in manufacture for a period of one year.

This does not affect your statutory rights.

Warranty number:

Operating Instructions

Manually Height Adjustable Table

Adjusting the height of your table

Fitted to the table is a square drive shaft that protrudes through a 25mm hole protected by a black rubber grommet. Supplied with the table is a black plastic crank-handle which should be fitted to the drive shaft and rotated in order to control the raising and lowering of the unit. Rotating the handle clockwise will raise the table, anti clockwise will lower it. The handle ceases to rotate at the upper and lower limits of the table.

Care should be taken to ensure that whilst the table assembly is moving downwards there are no obstructions left directly beneath the frame or worktop as this may result in damage to the obstruction or the crank-handle.

The crank-handle is fitted with nylon shear screws that are designed to break in the event of the handle receiving excessive force.

Should the nylon screws shear as designed, contact Astor-Bannerman at the address overleaf in order to arrange a replacement.

On no account should the nylon shear screws be replaced with non-standard components as this may result in damage to the table's internal mechanism.

Cleaning

The table and table top may be cleaned using most mild cleaning agents. **Chemical agents must not be used, i.e. drain cleaners, acetone, oven cleaners or acids.**

Attention should always be paid to instruction labels on the outside of cleaning agent containers.

Troubleshooting

In the unlikely event that problems occur with the unit, carry out the following easy checks to determine whether or not an engineer is required.

Fault: The table does not travel up or down.

Cause: The shear screws fitted to the crank-handle have sheared and the handle needs repair.

Remedy: Contact Astor-Bannerman at the address overleaf to arrange for a repair or replacement handle.

Fault: The table does not travel up or down and the handle is serviceable.

Cause: Damage has been caused to the internal mechanism of the table

Remedy: Contact Astor-Bannerman at the address overleaf to arrange for a repair.

If the problem persists after carrying out these remedies, please contact Astor-Bannerman using the details on the back cover.

Astor ♦ Bannerman

Unit 11f, Coln Park

Andoversford

Cheltenham

Glos, GL54 4HJ

Tel: 01242-820820

Fax: 01242-821110

e mail: sales@astorbannerman.co.uk