



## **Electrically Height Adjustable Table**



## **Owners Manual and Instructions for Use**



**IMPORTANT  
READ THIS  
MANUAL  
BEFORE USE**

### **Guarantee**

This product is guaranteed against all defects in manufacture for a period of one year.

This does not affect your statutory rights.

Warranty number:

# Operating Instructions

## Electrically Height Adjustable Table

### Adjusting the height of your table

The power supply for the table must be connected to operate the table. The height adjustable table is fitted with either a rocker switch or a two-button handset. By operating the rocker switch or the handset the table can be raised or lowered.

**NB: When the table reaches the end of its travel it will cut out automatically. Release the switch and wait for 10 seconds, until a clicking is heard, before the table will travel in the opposite direction.**

### Cleaning

The table and table top may be cleaned using most mild cleaning agents. **Chemical agents must not be used, i.e. drain cleaners, acetone, oven cleaners or acids.** The tap-set, side/end panels and handset should be cleaned using a warm soapy solution and rinsed with a damp cloth. **Attention should always be paid to instruction labels on the outside of cleaning agent containers.**

## Troubleshooting

In the unlikely event that problems occur with the unit, carry out the following easy checks to determine whether or not an engineer is required.

**Fault:** The table does not travel up or down

**Cause:** The mains power supply has been disconnected

**Remedy:** Examine the mains fuses/circuit breakers and reset as necessary and ensure that mains voltage is fully reconnected.

**Fault:** The table assembly does not travel up or down on a unit fitted with a handset.

**Cause:** The handset has been pulled from the socket fitted to the underside of the unit.

**Remedy:** Push the plug fitted to the handset more firmly into the socket.

**Fault:** The power supply has been checked but the table still does not travel up or down

**Cause:** Damage has been caused to the internal mechanism of the table

**Remedy:** Contact Astor-Bannerman at the address overleaf to arrange for a repair.

If the problem persists after carrying out these remedies, please contact Astor-Bannerman using the details on the back cover.



Unit 11f, Coln Park  
Andoversford  
Cheltenham  
Glos, GL54 4HJ  
Tel: 01242-820820  
Fax: 01242-821110

e mail: [sales@astorbannerman.co.uk](mailto:sales@astorbannerman.co.uk)