




## Installation Manual and Operating Instructions

..... BB-800, 900, 1000



- This Product should be installed according to this manual.
- Please read this manual carefully and install properly.
- Please keep this manual for future reference.
- Please register Warranty for proper service.



Thank you for purchasing BIO BIDET Supreme Bidet Seat (Electric Bidet).

This unit was manufactured for household use.

# Contents

- IMPORTANT SAFEGUARDS / ..... 4
- GENERAL CAUTIONS
- CAUTIONS BEFORE INSTALLATION ..... 6
- CARTON CONTENTS / IDENTIFICATION ..... 8

## PREPARATION

- OPERATION (BASIC) ..... 9
- OPERATION (DETAILS) ..... 10

## OPERATION

- INSTALLATION ..... 14
- SEPARATION OF THE UNIT FROM  
THE TOILET BOWL ..... 17

## INSTALLATION

- MAINTENANCE ..... 18
- WATER DRAINING ..... 19
- TROUBLE SHOOTING ..... 20
- SPECIFICATIONS ..... 21
- WARRANTY ..... 22
- INFORMATION TO THE USER ..... 23

## MAINTENANCE

## 1 IMPORTANT SAFEGUARDS / GENERAL CAUTIONS

### ● READ ALL INSTRUCTIONS BEFORE INSTALLATION AND USE

The following terms are used in this manual to indicate hazards of varying degrees of severity

<b>DANGER</b>	Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.
<b>WARNING</b>	Indicates potentially hazardous situation which, if not avoided, could result in death or serious injury.
<b>CAUTION</b>	Indicates potentially hazardous situation which, if not avoided, may result in minor or moderate injury or in damage to the product or other property.



**DANGER** – To reduce the risk of electrocution



**WARNING** – To reduce the risk of burns, electrocution, fire, or injury to persons



**PLEASE OBSERVE THE FOLLOWING PRECAUTION BEFORE USING THIS PRODUCT**




Do not dismantle

Do not open the product to repair or remodel.  
Only qualified service personnel should service this product.  
Do not use attachments not recommended by the manufacturer.



Prohibited

Connect the product to cold water supply pipe carrying potable water.  
Do not connect to an industrial water supply line that does not carry water of drinking quality.  
This will negatively effect hygiene and performance.



Prohibited


#### About Low Temperature Burns–

A burn occurs when the skin has been exposed to high temperatures. However, a low temperature burn may occur when the skin has been in contact with an object at relatively low temperature (about 104 °F/40°C). Close supervision is necessary when this product is used by, children or people with sensitive skin.



Prohibited

If using any chemical toilet bowl cleaner, be sure to wipe up any spills that splash onto Electric Bidet.  
Do not use benzene or any acid chemical detergent.  
Only neutral detergent permitted.








Prohibited

Do not plug in the power cord before connecting the water supply hose.




Grounding

This product must be grounded.  
An approved Ground Fault Circuit Interrupt, must be used.




Do not spray water

Do not splash water on this product. Please provide adequate ventilation to avoid damage to electronic components due to high level of humidity.  
it is necessary to provide adequate ventilation with a fan, open door or open window when bathing.




Wet hands prohibited

Do not touch the power cord with wet hands.  
Do not reach for a product that has fallen into water.  
Unplug immediately!




Observe at all times

This product must be connected to a standard voltage power source. Do not connect power cord if the cord is damaged or broken.  
Do not plug the unit into a loose electric outlet.



Observe at all times

Please disconnect the power cord when you clean this product or detach it from toilet bowl.  
Do not supply electrical power to the unit until the plumbing work has been completed.



Use of fire prohibited

Keep the electrical cord away from heated surfaces to prevent a fire hazard. Also, keep any flammable materials away at all times from the this product.





## CAUTION



Prohibited

Never operate this product if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the product to a service center for examination and repair



Prohibited

Do not obstruct or put anything into the dry air outlet. Do not apply excessive force to the shower nozzle.



Prohibited

Do not stand or sit on the seat cover lid. It is not designed to support a user's body weight.




Prohibited

Allow the seat and lid to close automatically do not force the seat and lid.



Prohibited

Do not strain or push the connected hose and tube connector; it may cause water leakage. Never drop or insert any object into any opening or hose. Use proper plumbing supplies if any modification is to be made.



Observe at all times

Use this product only as described in the operating instructions. Never use while sleeping or drowsy. Do not use while bathing.




Observe at all times

Be careful so that this product does not become stained with excrement and urine.



Observe at all times

drain the water from unit and switch off the power if it is not going to be used for an extended period of time. Refer to page 19



– SAVE THESE INSTRUCTIONS –

## 2

## CAUTIONS BEFORE INSTALLATION

### WIRING REQUIREMENT

THIS PRODUCT MUST BE PLUGGED into a regular voltage Grounded GFCI outlet (220–240V~, 50/60Hz). The rated power consumption is 600–700W.

In locations where only a standard two-prong outlet is available, it is the responsibility of the user to install a grounded three-prong outlet. Using a higher voltage is dangerous and may result in a fire or other accident. This product is not responsible for damage resulting from the use of it on other than specified voltage, or operating it without proper grounding.



## WARNING


This Product must be on a separated circuit. No other appliance should share the circuit with this product. Sharing a circuit could cause the branch circuit fuse to blow or the circuit breaker to trip. Continuous usage under these conditions could result in fire or property damage.

## GROUND INSTRUCTIONS

- (1) This product has a three-prong grounding plug, which must be plugged into an outlet that is properly installed and grounded.  
In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. If repair or replacement of the cord or plug is necessary, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire.  
Check with a qualified electrician or serviceman if the grounding instructions are not completely understood, or if in doubt as to whether the product is properly grounded.
- (2) If this product is used in a bathroom or in a shower room the supplied plug must be cut off and the connection to the power supply has to be performed by a qualified electrician.  
An ON / OFF switch should be installed.

**This appliance has to be earthed.**

## OPTIONAL GROUND INSTRUCTIONS



## DANGER


IMPROPER GROUNDING CAN RESULT IN A RISK OF ELECTRIC SHOCK. Electric wiring has to be done in accordance with all local codes, or in the absence of local codes, with the National Electrical Codes.

The use of an extension cord is not recommended or advised. If it is necessary to use an extension cord, use only a three-prong extension cord (one to one), and a three slot built-in GFCI receptacle that will accept the plug on this product. The marked rating of the extension cord should be equal to or greater than the electrical rating of the unit (10amp). Consult a qualified electrician or service person if you are not sure whether the unit is properly grounded.


# 3 IDENTIFICATION

## 1 MAIN UNIT


**BB-800, 900**



**BB-1000**




## 2 ACCESSORIES




## 4 OPERATION (BASIC)


### BB-800, 900 Control Panel



### BB-1000 Remote Control






### Simple Operation Panel



- When you sit on this product, please sit down on the central position in order to activate the sensor.
- After an extended wash, allow about three minutes for water to reheat.

## 5 OPERATION (DETAILS)

### 1 PREPARATION

- Check for any water leaks.
- Plug the unit into the proper power source and the LED power light will start flashing.
- Wait until the LED power light stops flashing and becomes solid red.
- The water tank will be filled after pushing a “Wash” (  ,  or  button.
- When the water tank is filling the buzzer “Beeps” continuously, after the water tank is full the buzzer will end with “One Solid Beep”.

### 2 OPERATION

#### SIT DOWN ON THE SEAT

- When you sit down on the seat, the ORANGE LED lamp on the control panel will light up.
- When the digital sensor on the seat is activated, the operation LED window on the main unit will light “Occupied sensor” and simultaneously, Deodorizer fan will start to work.  
(BB-900 / 1000 Models)
- See page 11 for details about changing the seat or water temperature.




#### STOP


- Press this button to stop all operation.

#### CLEANSING


##### • CLEANSING 1. (Posterior Wash)

- 1- Press “Posterior Wash” (  ). Automatically, the nozzle comes out and sprays warm water to posterior.
- 2- Additional functions during your Posterior Wash experience are available. See Oscillation, pg.12 and Massage, pg. 13 for details.

##### • CLEANSING 2. (Feminine Wash)

- 1- Press “Feminine Wash” (  ). Automatically, the nozzle comes out and sprays warm water to feminine area.
- 2- Additional functions during your Feminine Wash experience are available. See Oscillation, pg.12 and Massage, pg. 13 for details.

##### • CLEANSING 3. (Turbo Wash)

- 1- Press “Turbo Wash” (  ), the nozzle spray is more focused to produce the effect of strong wash, to help stimulate bowel movement.
- 2- Press “Water pressure – High & Low button” to adjust the water pressure.



Observe at all times





## CAUTION

DO NOT ALLOW CHILDREN TO USE THE **TURBO WASH** FUNCTION!  
 SUPERVISION IS STRONGLY RECOMMENDED FOR THE ELDERLY OR OTHER PERSONS  
 THAT MAY HAVE LIMITATIONS IN BODY MOVEMENT, ILLNESS OR DISABILITIES!

### CLEANSING cont.

#### • CLEANSING 3. (Turbo Wash)






- 1– Press “Turbo Wash” or continuously for 3 to 5 seconds. Automatically, the water nozzle comes out and sprays a warm stream of water to the posterior center of the rectum.
- 2– If necessary, adjust “Position” of water stream with the (↑,  / (↓,  ) buttons.
- 3– Press “Water pressure High & Low button” (⊕,  / (⊖,  ) to adjust the water pressure to your desired comfort.
- 4– Press the “STOP” (⏹) button when you feel your abdomen is full or wait until the “Turbo Wash” function stops, approximately 1 minutes.
- 5– You will shortly feel the urge to push the water out of your colon, push the water and feces out as completely as you can.
- 6– Relax for a few minutes and be sure you feel your colon is empty and then use the “Posterior Wash” and “Air Dry” function to finish.





DRY





#### WARM AIR DRYER

- 1– Press “Dry” (⏻,  ), warm, dry air is gently directed to washed area for about 3 minutes.
  - 2– You may adjust the warm air temperature by pressing High (⊕,  ) and Low (⊖,  ) buttons.
- ※ This product memorizes the air temperature of prior use.


### WATER PRESSURE ADJUSTMENT

- After sitting down on the this product, the LED lamp (●●●●) for water pressure on the Power Control will light at third or middle level (●●●●).
- Press high (⊕,  ), or low (⊖,  ) to adjust the pressure of the water spray to your desired comfort level


### WARM WATER TEMPERATURE AND SEAT TEMPERATURE ADJUSTMENT

- The temperature of water and seat are adjustable to the desired level by pressing the “WATER” (Ⓜ,  ) and “SEAT” (Ⓜ,  ) button.

WATER TEMPERATURE



SEAT TEMPERATURE



## 5 OPERATION (DETAILS)


### ● NOZZLE POSITION ADJUSTMENT

- Nozzle position is adjustable to the desired position by pressing “Front” (↑, (FRONT)) or “Rear” (↓, (REAR)) button from 1 to 5 positions.  
After using this product, the nozzle will return to position 3.

### ● DEODORIZER

(BB-900, 1000 Models)

- The deodorizer fan is activated when this product is occupied.  
When finished, the fan will stop after 1 minute.
- Air current for the deodorizer has 4 adjustable levels. While pressing the “STOP” (⏻) button, press and “WATER” (WATER, WATER) button to the desired air current level. See diagram:



### ● OSCILLATION ( Nozzle Movement Function)

- When using Posterior or Feminine Washing functions, pressing the “MOVE” (MOVE, MOVE) button will provide a short-motion, front to back oscillating spray for a much wider cleansing experience. Note: This function will not work during the “Turbo Wash” function.
- You may change the position of the Oscillating spray by pressing the “MOVE” (MOVE, MOVE) button again and “Front” (↑, (FRONT)) or “Rear” (↓, (REAR)) buttons simultaneously.
- Push the “MOVE” (MOVE, MOVE) button again and the oscillation motion will stop automatically.

#### Auto-Setting of Oscillation Feature

- You can set this function to automatically oscillate whenever the seat is occupied and the Posterior or Feminine washes are in operation.

**Step 1:** Do not sit on the this product.

**Step 2:** Press the “MOVE” (MOVE, MOVE) button for 3 seconds or until you hear a single Chime.

**Step 3:** Sit on the this product and proceed with Posterior or Feminine Wash.

**Note:** In the automatic setting, you may still adjust the position of the Oscillating spray by pressing the “Front” (↑, (FRONT)) or “Rear” (↓, (REAR)) buttons.









#### Canceling the Automatic Oscillation function

**Step 1:** Do not sit on the this product.

**Step 2:** Press the “MOVE” (MOVE, MOVE) button for 3 seconds or until you hear a double Chime.



## ● MESSAGE (Rhythm Wash)

- When using the Posterior Wash or Feminine Wash functions, pressing the “MESSAGE” (  ,  ) button will provide a pulsation spray.
- You may change the pressure of the spray by pressing the “High” (  ,  ) button or “Low” (  ,  ) buttons.
- Push the “MESSAGE” (  ,  ) button again and the pulsating action will stop automatically.





### Auto-Setting of Message Feature

- You can set this function to automatically pulsate whenever the seat is occupied and the Posterior or Feminine washes are in operation.

**Step 1:** Do not sit on the this product.

**Step 2:** Press the “MESSAGE” (  ,  ) button for 3 seconds or until you hear a single Chime.

**Step 3:** Sit on the this product and proceed with Posterior or Feminine Wash.

**Note:** In the automatic setting, you may still adjust the pressure of the pulsating spray by pressing the “high” (  ,  ) or “low” (  ,  ) functions.

### Canceling the Automatic Oscillation function

**Step 1:** Do not sit on the this product.

**Step 2:** Press the “MESSAGE” (  ,  ) button for 3 seconds or until you hear a double Chime.

## ● ECONOMY (Energy Save Mode)

- The ENERGY SAVER is not on when the LED light is off.
- Press button once to choose “ECONOMY 1”
- Press button again to choose “ECONOMY 2”
- Press button third time to turn “ECONOMY” off








\*The ECONOMY 1 : the water temperature will be kept at 90°F (32°C)

\*The ECONOMY 2 (SMART MODE) : this will lower the water temperature to 90°F (32°C) when it is not being used, and raise the water temperature back to normal level during the time of use.  
It takes about 4days for the unit to “learn”, and “remember”, the usage pattern of the user(s)

## ● NOZZLE CLEANING (Automatically)

- This product has an automatic nozzle self-cleaning function that cleans the nozzle before and after each use.

## ● NOZZLE CLEANING (Manual)

- Nozzle can be cleaned manually by pressing “Posterior Wash” (  /  ,  ) button for 3 seconds without being occupied on the seat and nozzle will come out without spraying water. After cleaning the nozzle, Press “Stop” (  ,  ) button to return nozzle to stand-by mode.  
(  ,  : in Simple Operation panel –Remote Model)

## ● CHIME SOUND ON/OFF SET

- While sitting on the this product, press “MOVE” (  ,  ) button for 3 seconds and you can hear the chime sound change to ON or OFF. (Remote model doesn’t have off function, BB-1000)

## 6 INSTALLATION




### CAUTION BEFORE INSTALLATION

- Do not connect to electricity before water connection.
- If you need an electric power system or extension, please consult a qualified electrician.

### STEPS

**1**

Shut off the water supply to the existing toilet tank by closing the angle stop valve. Drain the toilet tank completely by flushing toilet. Remove the water supply hose to toilet tank.



**2**



**Removing the existing seat and lid.**

- Release the nuts on both sides of existing toilet seat to remove the seat and lid.



**3**


Remove existing supply pipe from the cistern tank and connect the tee to the cistern tank. Connect the double check valve supplied to the tee and the 1/2" male-male adaptor to the check-valve, connect existing supply pipe to the tee. An approved double-check valve must be installed on the inlet connection to this device.



※Check for any water leaks. (TEFLON tape is strongly recommended around threads to help prevent leakage)


#### 4 Installation Base Assembly.

1. Put the 2 Bolts into the 2 Installed Bolt Cases
2. Place this Bolt assembly into the Installation Base as shown.
3. Guide Arrows on the Installation Base should face up and towards the Toilet Tank.
4. Place the Installation Base and guide the Bolts into the 2 holes on the toilet bowl.




#### 5 Bolt and Nut Assembly.

1. Fit the cone packing and plastic washers onto the bolts from below the toilet bowl as shown.
2. Loosely tighten nuts by hand.




#### 6 Bio Bidet Shower Toilet Seat Assembly.

1. Slide the seat onto the installation Base centering the unit with the guide arrows on the Base.
2. You will hear a click once the seat is securely mounted to the Installation Base.
3. The seat will feel a little loose on the toilet bowl. Adjust the fit from front to back and side to side for balance.
4. Tighten the nuts on both bolts securely.



#### 7 Water Supply Tube Assembly.

1. Connect the flexible tube from male—male Adaptor to the seat.
2. Open the water valve.
3. Check for leaks.
4. If there are no leaks and the surrounding area is clean and dry, connect the power cord to a ground protected power outlet.




※Check for any water leaks. (TEFLON tape is strongly recommended around threads to help prevent leakage)

## 6 INSTALLATION

### 9 Deodorizer Installation.


Insert the deodorant cartridge into the unit.  
(BB-900 / 1000 Models)



How to change the deodorant catalyst


1

- Check the deodorant package.
- Follow the below photos to change the deodorant.



2

Insert the new deodorant case into the unit.



### 10 Installation of Remote Control on wall or convenient surface. (BB-1000)




1- Mount Fixed Panel to wall location.  
Take off the cover on the adhesive on  
Remote Control Fixed Panel or use  
adhesive tape in order to adhere  
Remote Control Fixed Panel on wall.



2- Then slide Remote Control on to  
Remote Control Fixed Panel.


Adhesive Tape



Place 1.5V(AA) batteries properly  
and shut the cover

## 7 SEPARATION OF UNIT FROM THE TOILET BOWL

- 1 Switch off power supply.
- 2 Shut off the Water Supply Valve.




- 3 Push the button on the right side of the unit to completely drain the water from water tank.

- 4 Separate the unit from toilet as following photos.








- When you pull the unit while pushing the drain button, the unit will separate from the installation base.


 Do not turn unit upside down.



## 8 MAINTENANCE

### CLEANING THE NOZZLE

- When the “Posterior Wash (  /  ,  )” button is pressed for 3 seconds without occupying the seat, the nozzle can be cleaned with a soft toothbrush.
- (  : in Simple Operation panel –Remote Model)
- After cleaning the nozzle, push the “Stop (  ,  )” button once again, and the nozzle retracts itself.
- (  : in Simple Operation panel –Remote Model)





### CLEANING THE BODY OF UNIT

- When you clean the this product, do not use “thinner”, “benzene” or toilet bowl cleaner. It may cause damage to the surface of unit.
- Use a wet cloth when you clean the this product.
- Do not spray water directly on to the this product.
- When you clean the this product, switch off power supply.


### CLEANING THE STRAINER

**This product will not operate properly if the strainer is clogged. Please clean the strainer regularly.**

- 1) Close the water shut off valve.
- 2) Flush the toilet to empty the water reservoir.
- 3) Unscrew the water filter nut.
- 4) Clean the strainer with a small brush or water.
- 5) Re-screw the water filter nut.
- 6) Open the water shut off valve.



BB-800, 900





BB-1000

## 9 WATER DRAINING

### ● DRAINING THE WARM WATER TANK IN THE UNIT

If you do not intend to use the this product for 14 days or longer, drain the water from the product warm water tank.

- 1) Disconnect the power plug.
- 2) Close the water shut off valve.
- 3) Press the drain lever until the water is completely drained from the unit's water tank.
- 4) To re-supply water after draining, open the water shut off valve.



Do not drink the drained water.  
Do not insert finger into the drain hole.  
Before draining, switch off power and wait 30 minutes until the unit has cooled down.

## MAINTENANCE FOR WINTER SEASON

- 1 Check the power is ON or OFF.
- 2 Keep the water temperature on "Middle or High Level" to prevent water from freezing.
- 3 If you do not intend to use the unit for 14 days or longer, switch the power off and drain the water.

# 10 TROUBLE SHOOTING

Trouble	Cause	Remedy
The washing water does not spray	1.The water tank is not filled. 2.The shut off valve is closed. 3. Freezing inside the main unit or the water supply pipe.	1. Wait about one minute. 2.Press the desired washing button once again. 3.Turn on the shut off valve to open. 4.Heat the room (for about two hours). Operating the unit while parts are frozen will cause a malfunction.
The unit is not operating	1.Power is switched off. 2.The seat is not occupied. 3.The battery of remote controller is exhausted. (Only BB-1000 model)	1.Switch power on. 2. Check the power supply system in your house. 3.Occupy the seat (The unit has an occupied sensor). 4.Replace the battery.
Water is leaking	1.Check the water supply system	1. If water is leaking from the main unit, call the service center or the place you purchased.
The washing water pressure is weak	1.The water pressure level is set to "LOW". 2.The strainer is clogged.	1.Set the water pressure to "HIGH". 2.Clean the strainer.
The washing water is not warm	1.The water temperature is set to "LOW". 2.Continuous operation has depleted the supply of warm water.	1.Set the water temperature to "HIGH". 2. Wait about three minutes.
The seat and dryer is not warm	1.The seat & dryer temperature is set to "LOW".	1. Set the seat & dryer temperature to "HIGH".



# 11 SPECIFICATIONS

Specification		BB-800	BB-900	BB-1000	
Power Rating		Australia or Europe: 220 – 240V~, 50/60Hz , 600 – 700W America or Canada: 120Vac, 60Hz, 660W			
Water inlet type	Type	Direct Inlet flow type			
	Water inlet pressure	0.4 ~ 7.5 kgf/cm²( 5.69 psi ~ 106.7psi )			
Power cord		(1.2m (4 feet): AMERICA) / (1.8m:Australia or Europe)			
Wash Device	Posterior Wash	Max. 1.2 ℓ /min ( Max. 0.32 GPM )			
	Feminine Wash	Max. 1.2 ℓ /min ( Max. 0.32 GPM )			
	Water Pressure Adjustable	5 Levels			
	Warm Water Temperature	Room Temp – 40℃ ( Room Temp. 104°F )			
	Heater	600 W			
	Safety Devices	Thermal fuse, Thermal switch, Float switch			
Heated Seat	Temperature	Room Temp ~ 41℃ ( Room Temp. ~ 105.8°F )			
	Heater	55 W			
	Safety Device	Thermal fuse			
Warm Air Dryer Device	Adjustable Dry Temperature (Room Temp~45℃)	○	○	○	
	Heater (250W)				
	Safety Device (Thermal fuse, bimetal)				
Turbo& Enema Function		○	○	○	
Deodorizer		–	○	○	
Remote control		–	–	○	
Inlet water temperature		3℃~ 35℃ ( 37.4°F ~ 95°F )			
Ambient Temperature		3℃~ 40℃ ( 37.4°F ~ 104°F )			
Dimension		Elongated(Control)	Round (Control)	Elongated (Remote)	Round (Remote)
		W : 495mm (19.4 inch)	W : 495mm (19.4 inch)	W : 475mm (18.7 inch)	W : 475mm (18.7 inch)
		L : 525mm (20.6 inch)	L : 493mm (19.4 inch)	L : 525mm (20.6 inch)	L : 493mm (19.4 inch)
		H : 185mm (7.28 inch)	H : 185mm (7.28 inch)	H : 185mm (7.28 inch)	H : 185mm (7.28 inch)
Weight (kg)		5.3kg	5.4kg	5.2kg	

# 12 WARRANTY

## UCI, INC. Limited Warranty

### BB-1000 Three-Year Limited Warranty

100% Coverage of all parts and labor for the entire product for the first year from original date of purchase

75% Coverage of all parts and labor for the entire product for the second year from original date of purchase

50% Coverage of all parts and labor for the entire product for the third year from original date of purchase

1. The UCI, INC. warrants the Supreme Bidet Seat to be free from manufacturing defects under normal and intended use. This warranty is extended only to the original retail buyer and residential location for a period of (1) years from the date of purchase.
2. The UCI, INC. obligations are limited only to the repair or replacement of the Supreme Bidet Seat that we find to be defective provided that the Supreme Bidet Seat was properly installed and used according to the instruction manual included.
3. The UCI, INC. will not charge for Labor or parts in connection with the repair or replacement of the Supreme Bidet Seat.
4. The UCI, INC. will not be responsible for any consumer costs related to the removal, return to The UCI, INC. and / or reinstallation of the Supreme Bidet Seat.
5. The UCI, INC. will not be responsible for any consumer loss related to incidental, consequential damages or expenses incurred by the purchaser.
6. Not covered by this warranty are:
  - Loss or damage from fire, flood, freeze, electrical storm or any other natural calamity or act of God.
  - Defects or malfunctions resulting from failure to properly install, operate and/or maintain the Supreme Bidet Seat to residential water toilets in accordance with the enclosed installation manual.
  - Loss or damage from misuse, abuse or negligence.
  - Damage resulting from unauthorized alterations, attachments and/or repairs.
  - Loss or damage from installing the unit in a harsh or hazardous environment and/or an environment including animals, mice or insects.
  - Damage caused from excess moisture or from sediments or foreign matter contained in the water system.
  - Damage from not being installed in accordance with all local codes, ordinances and good trade practices.
  - Color fading due to an installation in the wrong environment.
  - Loss or damage from consumable chemicals such as chlorinates (found in public water supplies) or from cleaning agents warned about in the installation manual.
  - Damage to the toilet bowl that the Supreme Bidet Seat is installed to.
7. The UCI, INC. will only warrant products with returned registration cards or from on-line registration with proof of purchase within 30 days of the original purchase date.
8. This warranty is also void if the "CAUTION" label is removed from the inside of the Supreme Bidet Seat cover.
9. This limited warranty gives you specific legal rights and you may also have other rights that may vary from state to state.

**This is the UCI's exclusive limited warranty.**

# 13 INFORMATION TO THE USER

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## WARNING

Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

**Note :** The manufacturer is not responsible for any Radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

## WARRANTY REGISTRATION

To ensure your warranty protection you must complete and return this card along with a copy of your receipt to The UCI, INC. within 30 days after Date of Purchase.

Model \_\_\_\_\_ Serial Number # \_\_\_\_\_

Purchaser \_\_\_\_\_ Date of Purchase \_\_\_\_\_

company \_\_\_\_\_

Address \_\_\_\_\_

City \_\_\_\_\_ Country \_\_\_\_\_

Phone \_\_\_\_\_ E-mail \_\_\_\_\_

Dealer(Company) \_\_\_\_\_

Dealer Code \_\_\_\_\_

Address \_\_\_\_\_

## MAIL TO :

Precision Design Service Limited  
GREYFRIARS  
SPIXWORTH ROAD  
OLD CATTON  
NORWICH  
NORFOLK NR6 7DX  
Telephone: +44(0)1603 408126  
Fax: +44(0) 871 781 8428



UCÍ

lifestyle upgrade

[www.biobidet.com](http://www.biobidet.com)

**DISTRIBUTOR**

Precision Design Service Limited

GREYFRIARS, SPIXWORTH ROAD, OLD CATTON

NORWICH


NORFOLK NR6 7DX

Telephone: +44(0)1603 408126

Fax: +44(0) 871 781 8428

# OPERATION

BB-800, 900



## Sit on the seat

- When sitting on the seat, the Orange LED on the control panel will light and the deodorizer fan will start to run.
- Push "SEAT" , to adjust temperature.

## Push the desired function button



- All washing functions work for one minute.
- Push "WATER" , to adjust temperature.

## How to operate




### 1st Step

Push "Turbo Wash", "Enema Wash" button, and adjust the washing features on the control center.



### 2nd Step

After a few minutes, strain your abdomen to eliminate the waste matter from your system.



## Push "Dry" function

- You can adjust air temperature by Pushing "High( , )" or "Low( , )" button.
- Automatically stops after 3 minutes.

## Nozzle & Move Position Control



- Push( , ) or ( , ) to adjust spray position.

## Water Pressure Control





- Push( , ) or ( , ) to adjust the water pressure.

## Rhythm Wash Control

- Push( , ) MESSAGE button.

## Press "Stop" Button to stop all operations

BB-1000



Simple Operation Panel (BB-1000 model)

## NOTICE

When users do not use remote control for 10 seconds, the LED lamp will turn off in order to save the battery power. (BB-1000 model)