

Quick Guide: A2B Ceiling Hoist

- Do NOT attempt to lift a higher load than the SWL (safe working load) of the hoist. See side of hoist (normally 200kg).
- Only trained personnel should use the Ceiling Hoist
- Read the User Manual before use.
- Do NOT pull the hoist by the handcontrol.
- Do NOT wrap the handcontrol cord around the spreader bar and lower the spreader bar, this will snap the cord.
- Always return the hoist to the Charging Station when not in use.
- Only use approved loop slings (or clip slings if the cradle is fitted).

Hand control

- The hand control will operate the hoist up and down (also left/right if you have a 4 function motor or tilting spreader if fitted).
- For horizontal drive the white and blue arrow match the white and blue arrow on the hoist.

Charging

- When not in use the Motor should be stored at the Charging Station.
- If the hoist needs charging the orange light will illuminate when the hoist is under the Charging Station.

Lights

- Permanent Orange Light = Hoist is Charging
- Flashing Orange Light = Charge required, return to charging station
- Green Light = Hoist is on, all functioning OK
- Red Spanner Light = Service or maintenance required.



Problem	Solution
Hoist not working (no lights on control panel)	Return hoist to charging station, leave for two hours minimum. Ensure emergency cord hasn't been pulled if pulled, push button all the way back in to reset.
Charging Light Flashing, Hoist slow to use	Return hoist to charging station, leave for 2 hours minimum.
Handcontrol cord is broken at plug	Usually this is due to the handcontrol being wrapped around the spreader bar. Contact Astor-Bannerman to purchase a replacement.
Service Light (red spanner) is On but Hoist works OK	Service is required.

Regular Servicing

Your A2B ceiling hoist will require maintenance to ensure it is safe to operate. This service must be carried out by a competent, trained professional every 6 months according to LOLER and ISO10535.

For more information and to arrange a service, please contact Astor-Bannerman (Tel: 01242 820820 / Email: sales@astorbannerman.co.uk).